## **INSTAX-ADX5VI-CH1**

#### **AX-ADX5VI-CH1**

## 2004-2010 Chrysler accessory and NAV output CAN harness

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (retained accessory power)
- Used in non-amplified systems, or when replacing amplified system
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- Prewired ASWC-1 harness included (ASWC-1 sold separately)
- · High level speaker input
- USB updatable

Note: This harness must be used in conjunction with the AX-ADXSVI

## **APPLICATIONS**

CHRYSLER		Ram 1500	2006-2008
300	2005-2007	Ram 2500/3500	2006-2009
Aspen	2007	JEEP	
PT Cruiser	2006-2010	··	
		Commander	2006-2007
DODGE		Compass	2007-2008
Caliber	2007-2008	Grand Cherokee	2005-2007
Charger	2006-2007	Patriot	2007-2008
Dakota	2005-2007	MITSUBISHI	
Durango	2004-2007		2000 2007
Magnum	2005-2007	Raider	2006-2007

## **WIRING THE AX-ADXSVI-CH1**

- Connect the Yellow wire to the radio's 12 volt battery or memory wire.
- · Connect the Black wire to the radio's ground wire.
- Connect the **Red** wire to the ignition wire of the aftermarket radio.
- Connect the Orange wire to the illumination wire of the aftermarket radio. If the
  aftermarket radio has no illumination wire, tape off the Orange wire.
- Connect the **Blue** wire to the antenna turn on wire of the aftermarket radio.
- Connect the White wire to the left front positive speaker output of the aftermarket radio.

∄ 1-8	00-221-0932		metraonline.com
REV. 12/12/13	© COPYRIGHT 2004-2013	METRA ELECTRONIO	CS CORPORATION

#### INSTAX-ADXSVI-CH1

#### **AX-ADX5VI-CH1**

# 2004-2010 Chrysler accessory and NAV output CAN harness

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (retained accessory power)
- Used in non-amplified systems, or when replacing amplified system
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- Prewired ASWC-1 harness included (ASWC-1 sold separately)
- · High level speaker input
- USB updatable

Note: This harness must be used in conjunction with the AX-ADXSVI

# **APPLICATIONS**

CHRYSLER		Ram 1500	2006-2008
300	2005-2007	Ram 2500/3500	2006-2009
Aspen	2007	JEEP	
PT Cruiser	2006-2010	Commander	2006-2007
DODGE		Compass	2007-2008
Caliber	2007-2008	Grand Cherokee	2005-2007
Charger	2006-2007	Patriot	2007-2008
Dakota	2005-2007	MITSUBISHI	
Durango	2004-2007	Raider	2006-2007
Magnum	2005-2007	naiuei	2000-2007

## **WIRING THE AX-ADXSVI-CH1**

- Connect the Yellow wire to the radio's 12 volt battery or memory wire.
- Connect the **Black** wire to the radio's ground wire.
- Connect the **Red** wire to the ignition wire of the aftermarket radio.
- Connect the Orange wire to the illumination wire of the aftermarket radio. If the
  aftermarket radio has no illumination wire, tape off the Orange wire.
- Connect the **Blue** wire to the antenna turn on wire of the aftermarket radio.
- Connect the White wire to the left front positive speaker output of the aftermarket radio.

# T-800-221-0932 metraonline.com REV. 12/12/13 © COPYRIGHT 2004-2013 METRA ELECTRONICS CORPORATION

## **INSTAX-ADX5VI-CH1**

#### **AX-ADX5VI-CH1**

## 2004-2010 Chrysler accessory and NAV output CAN harness

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (retained accessory power)
- Used in non-amplified systems, or when replacing amplified system
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- Prewired ASWC-1 harness included (ASWC-1 sold separately)
- · High level speaker input
- USB updatable

Note: This harness must be used in conjunction with the AX-ADXSVI

## **APPLICATIONS**

CHRYSLER 300	2005-2007	Ram 1500 Ram 2500/3500	2006-2008 2006-2009
Aspen PT Cruiser	2007 2006-2010	JEEP	
FT Gruisei	2000-2010	Commander	2006-2007
DODGE		Compass	2007-2008
Caliber	2007-2008	Grand Cherokee	2005-2007
Charger	2006-2007	Patriot	2007-2008
Dakota	2005-2007	MITSUBISHI	
Durango	2004-2007	Raider	2006-2007
Magnum	2005-2007	naiuei	2000-2007

## **WIRING THE AX-ADXSVI-CH1**

- Connect the **Yellow** wire to the radio's 12 volt battery or memory wire.
- · Connect the Black wire to the radio's ground wire.
- Connect the Red wire to the ignition wire of the aftermarket radio.
- Connect the Orange wire to the illumination wire of the aftermarket radio. If the
  aftermarket radio has no illumination wire, tape off the Orange wire.
- Connect the Blue wire to the antenna turn on wire of the aftermarket radio.
- Connect the White wire to the left front positive speaker output of the aftermarket radio.



#### **INSTAX-ADXSVI-CH1**

#### AX-ADX5VI-CH1

# 2004-2010 Chrysler accessory and NAV output CAN harness

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (retained accessory power)
- Used in non-amplified systems, or when replacing amplified system
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- Prewired ASWC-1 harness included (ASWC-1 sold separately)
- High level speaker input
- USB updatable

**Note:** This harness must be used in conjunction with the AX-ADXSVI

## **APPLICATIONS**

ALLEGATIONS				
	Ram 1500	2006-2008		
	Ram 2500/3500	2006-2009		
	IEED	,		
2006-2010		0000 0007		
		2006-2007		
	Compass	2007-2008		
2007-2008	Grand Cherokee	2005-2007		
2006-2007	Patriot	2007-2008		
	MITCHDICHI			
2004-2007		2006-2007		
2005-2007	naiuei	2000-2007		
	2005-2007 2007 2006-2010 2006-2010 2006-2007 2005-2007 2004-2007	2005-2007 2006-2010  2007-2008 2007-2008 2006-2007 2005-2007 2005-2007 2004-2007  Ram 1500 Ram 2500/3500  JEEP Commander Compass Grand Cherokee Patriot  MITSUBISHI Paider		

# WIRING THE AX-ADXSVI-CH1

- Connect the **Yellow** wire to the radio's 12 volt battery or memory wire.
- Connect the Black wire to the radio's ground wire.
- Connect the **Red** wire to the ignition wire of the aftermarket radio.
- Connect the Orange wire to the illumination wire of the aftermarket radio. If the
  aftermarket radio has no illumination wire, tape off the Orange wire.
- Connect the **Blue** wire to the antenna turn on wire of the aftermarket radio.
- Connect the **White** wire to the left front positive speaker output of the aftermarket radio.



#### INSTAX-ADX5VI-CH1



- Connect the White/Black wire to the left front negative speaker output of the aftermarket radio.
- Connect the Gray wire to the right front positive speaker output of the aftermarket radio.
- Connect the Gray/Black wire to the right front negative speaker output of the aftermarket radio.
- Connect the **Green** wire to the radio's left rear positive speaker output.
- Connect the Green/Black wire to the radio's left rear negative speaker output.
- Connect the **Purple** wire to the radio's right rear positive speaker output.
- · Connect the Purple/Black wire to the radio's right rear negative speaker output.

The following wires are for the aftermarket radios that have navigation built in.

- · Connect the Light Green wire to the parking brake wire of the aftermarket navigation radio (if applicable).
- Connect the Blue/Pink wire to the VSS or speed sense wire of the aftermarket navigation radio (if applicable).
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio (if applicable).
- Cycle the key, by turning the ignition on for 30 seconds. Then off and on again to test the radio.

## ASWC-1 (if installing)

After the XSVI is initialized, plug in the ASWC-1 into the 12-pin harness of the AX-ADXSVI-CH1 and refer to the ASWC-1 instructions.






Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio

1-800-221-0932



© COPYRIGHT 2004-2013 METRA ELECTRONICS CORPORATION REV. 12/12/13

#### **INSTAX-ADX5VI-CH1**



- Connect the White/Black wire to the left front negative speaker output of the aftermarket radio.
- Connect the Gray wire to the right front positive speaker output of the aftermarket radio.
- Connect the Gray/Black wire to the right front negative speaker output of the aftermarket radio.
- Connect the **Green** wire to the radio's left rear positive speaker output.
- Connect the Green/Black wire to the radio's left rear negative speaker output.
- Connect the **Purple** wire to the radio's right rear positive speaker output.
- Connect the Purple/Black wire to the radio's right rear negative speaker output.

The following wires are for the aftermarket radios that have navigation built in.

- Connect the **Light Green** wire to the parking brake wire of the aftermarket navigation radio (if applicable).
- Connect the Blue/Pink wire to the VSS or speed sense wire of the aftermarket navigation radio (if applicable).
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio (if applicable).
- Cycle the key, by turning the ignition on for 30 seconds. Then off and on again to test the radio.

# ASWC-1 (if installing)

After the XSVI is initialized, plug in the ASWC-1 into the 12-pin harness of the AX-ADXSVI-CH1 and refer to the ASWC-1 instructions.





Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio.

# 1-800-221-0932



🖳 metraonline.com

INSTAX-ADX5VI-CH1



- Connect the White/Black wire to the left front negative speaker output of the aftermarket radio.
- Connect the Gray wire to the right front positive speaker output of the aftermarket radio.
- Connect the Gray/Black wire to the right front negative speaker output of the aftermarket radio.
- Connect the **Green** wire to the radio's left rear positive speaker output.
- Connect the Green/Black wire to the radio's left rear negative speaker output.
- Connect the **Purple** wire to the radio's right rear positive speaker output.
- Connect the **Purple/Black** wire to the radio's right rear negative speaker output.

The following wires are for the aftermarket radios that have navigation built in.

- · Connect the Light Green wire to the parking brake wire of the aftermarket navigation radio (if applicable).
- Connect the Blue/Pink wire to the VSS or speed sense wire of the aftermarket navigation radio (if applicable).
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio (if applicable).
- Cycle the key, by turning the ignition on for 30 seconds. Then off and on again to test the radio.

#### ASWC-1 (if installing)

After the XSVI is initialized, plug in the ASWC-1 into the 12-pin harness of the AX-ADXSVI-CH1 and refer to the ASWC-1 instructions.




KNOWLEDGE IS POWER



Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio

1-800-221-0932



© COPYRIGHT 2004-2013 METRA ELECTRONICS CORPORATION

#### **INSTAX-ADX5VI-CH1**



- Connect the White/Black wire to the left front negative speaker output of the aftermarket radio.
- Connect the Gray wire to the right front positive speaker output of the aftermarket radio.
- Connect the Gray/Black wire to the right front negative speaker output of the aftermarket radio.
- Connect the **Green** wire to the radio's left rear positive speaker output.
- Connect the **Green/Black** wire to the radio's left rear negative speaker output.
- Connect the **Purple** wire to the radio's right rear positive speaker output.
- Connect the Purple/Black wire to the radio's right rear negative speaker output.

The following wires are for the aftermarket radios that have navigation built in.

- · Connect the Light Green wire to the parking brake wire of the aftermarket navigation radio (if applicable).
- Connect the Blue/Pink wire to the VSS or speed sense wire of the aftermarket navigation radio (if applicable).
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio (if applicable).
- Cycle the key, by turning the ignition on for 30 seconds. Then off and on again to test the radio.

# ASWC-1 (if installing)

After the XSVI is initialized, plug in the ASWC-1 into the 12-pin harness of the AX-ADXSVI-CH1 and refer to the ASWC-1 instructions.



air bag indicator lights must be plugged in before

reconnecting the battery or cycling the ignition. Note: Refer to the instructions included with the aftermarket radio.

Caution: Metra recommends disconnecting the negative battery terminal before beginning any

installation. All accessories, switches, and especially

